



N° Object	Code	Description	Qty
1014	ZS2026	Termostat TY60 N.O. fixing B	2
1441	ZS2665	Support for fan timelag device	1
1575	ZS2931	Spacer between glasses	2
1606	ZS2995	Fixing spring for front profile	16
2000	ZS3185	Back splash for cooker 100 Ascot	1
2052	ZS3643	Support for internal support control panel 100 Ascot	1
4102	ZS6591	Control panel front 6 induction Ascot 100 TC S.STEEL with serygr.	1
4211	ZS5378	Induction 5 element EGO	1
4266	ZS6787	Encoders control board	1
4305	GR6900	Assembly cooktop cooker 100 double oven induction Ascot	1
1957	ZS3495	Washer 4.3 x 10 x 3	4
4321	ZS6726	Glass for 100 induction hob or cooker	1
5038	ZS7683	Complete upper right side Ascot VTRC/IND	1
5039	ZS7684	Complete upper left side Ascot VTRC/IND	1
5190	ZS8174	Handle for hob cooker Ascot 100 chromed terminal nickel	1
5783	ZS6817	Feet for electronic components EGO	3
5784	ZS6904	Cover for induction terminal board	1
5785	ZS6905	Bridge for induction terminal board	1
6036	ZS8446	Clamp support for induction 90/100 Sintesi front / rear	2
6038	ZS8877	Support for electronic control induction element	1
6154	ZC0334	Profile control panel drawer 100 Ascot internal black	1
6215	ZP0425	Support for fan timelag device	1
6308	ZP0412	Profile control panel drawer 100 Ascot external inox	1




N° Object	Code	Description	Qty
129	601154	Timer	1
2003	ZS3195	Commutator support 2 positions	3
3330	ZS5412	Ascot chromed knob	6
3717	ZS6026	Switch for induction encoder	5
4210	ZS5377	Energy regulator for induction 230 V EGO EU	5




N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
107	482120	Thermostat cooker 192	1
455	ZS1075	Oven thermostat	2
538	ZS1204	Led transparent	3
823	ZS1755	Fluorescent orange warning light	3
2016	ZS3227	Commutator support 3 positions	1
2067	ZS3785	Knob for timer gray	5
3330	ZS5412	Ascot chromed knob	3
3922	ZS6184	Timer (white led) LCD-ELA 1000	1
5074	ZS7893	Commutator oven functions 060 R	2


N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
20	401520	Black cap for glass front panel	2	4169	ZS6686	Muffle fan guard cooker 100 double/Triple oven Steam	1
98	481913	Terminal block for oven 32 PA 233	1	6199	ZP0348	Air conveyor for cooktop 100 double / triple oven	1
123	541011	Spacer washer for built-in oven	4	6200	ZP0349	Air conveyor for cooktop SX	1
392	ZS0903	Sintesi black foot H.15	4	6201	ZP0350	Air conveyor for cooktop DX	1
1296	ZS2442	Rear central support for muffle 60 DC	1				
1297	ZS2443	Rear central support for muffle 30	1				
1298	ZS2444	Rear support for muffle left side oven 60 cooker 100 triple oven	1				
1317	ZS2475	Front support for muffle left/right side 100/120 double/triple oven cooker	1				
1318	ZS2477	Rear support for muffle left/right side cooker 100 double/triple oven	1				
1414	ZS2601	Terminal board support	1				
1439	ZS2663	Cooling fan L=180 Plaset (AU)	2				
1459	ZS2446	Left side drawer compartment for cooker 100 triple oven	1				
1461	ZS2448	Drawer upper guard for cooker 100 triple oven	1				
1466	ZS2501	Front central muffle support for cooker 100 triple oven	1				
1948	ZS3225	Complete lower right/left side Ascot S.STEEL	2				
2024	ZS3305	Fixing plate for top Ascot	2				
2209	ZS3811	Plinth for cooker 100 triple oven Neff	1				
3024	GR4817	Assembly complete lower guard for cooker 100 triple oven Ascot	1				
130	601156	Tapping screw M10 galvanized	5				
2808	ZS4115	Lower reinforcement for right/left side cooker 70 double oven Ascot	2				
3034	ZS4817	Lower guard for cooker 100 triple cavity 04	1				
3038	ZS4822	Reinforcement for lower guard cooker 100 triple oven external	2				
3040	ZS4826	Reinforcement for lower guard cooker 100 triple oven internal	2				
3035	ZS4818	Right side drawer compartment for cooker 100 triple oven	1				
3037	ZS4821	Front support for muffle left side 100 TC	1				
3039	ZS4823	Rear guard for cooker 100 triple oven Ascot	1				
3712	ZS5978	Ramp hole closing plate	1				
4167	ZS6684	Spacer for drawer guide	2				



N° Object	Code	Description	Qty
82	481403	Thermoswitch 16 Ampere	1
128	601152	Spring fixing feeler for built-in oven	2
566	ZS7590	Lower heating element for oven 60 (1200W/230V)	1
1209	414559	Lateral frame support for built-in oven	6
1218	ZS2284	Oven lateral frame 60 R/L	2
1219	ZS2286	Chromed wire grid for oven 60	1
1260	ZS2395	Hinge support 06	2
1305	ZS2456	Lower heating elem.support oven 60 double oven 04	1
1306	ZS2459	Lower heating element tray oven 60 04	1
1307	ZS2460	White glass wool for rear side grilling 60 oven	1
1320	ZS2489	Trivet for oven 60 04	1
1425	ZS2632	White glass wool for 60 oven 04	1
1467	ZS2604	Support for safety thermostat 04	1
1760	ZS3078	Telescopic liner left	1
1761	ZS3079	Telescopic liner right	1
1832	482094	Grill heating element for oven 60 (1900+850W)	1
3937	ZS6339	Ceramic tiles for oven	1
4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	1
4131	ZS6540	Gasket grilling oven 60 P H=8.9 mat HT	1
6278	ZC0349	Enamelled muffle ceiling oven 60 grey	1
6279	ZC0352	Enamelled muffle front side oven 60 DC grey	1
6283	ZC0356	Enamelled drip tray for oven 60 grey	1
6285	ZC0358	Side muffle oven 60 P enamelled grey	2
6287	ZC0362	Muffle rear side oven 60 P enamelled grey	1
6288	ZC0366	Grill heating element support for muffle oven 60 enamelled grey	1
6300	ZC0360	Enamelled muffle bottom for oven 60 grey	1




N° Object	Code	Description	Qty
3026	GR5116	Assembly glued oven door 60 P/100 triple oven Ascot	1
2939	GR4315	Assembly door grilling oven 60 right bar profile 07	1
2940	GR4316	Assembly door grilling oven 60 left bar profile 07	1
1223	ZS2310	Inner glass oven door 60 P	1
1258	ZS2392	In-between glass oven door 60 P 04	1
1278	ZS2415	Door hinge for grilling oven 60	2
1280	ZS2419	Spring for door glass assembling 04	4
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
3052	ZS5116	Glued external grilling oven door 60/100 triple oven	1
5193	ZS8177	Handle for oven door 60 Ascot 70/100 chromed terminal nickel	1




N° Object	Code	Description	Qty
82	481403	Thermoswitch 16 Ampere	1
128	601152	Spring fixing feeler for built-in oven	2
1209	414559	Lateral frame support for built-in oven	6
1217	ZS2283	Oven lateral frame 30/60/90	2
1219	ZS2286	Chromed wire grid for oven 60	1
1260	ZS2395	Hinge support 06	2
1424	ZS2629	White glass wool for rear side 60 oven 04	1
1425	ZS2632	White glass wool for 60 oven 04	2
1467	ZS2604	Support for safety thermostat 04	1
1760	ZS3078	Telescopic liner left	1
1761	ZS3079	Telescopic liner right	1
2891	482589	Circular heating element 230V-2100W	1
4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	1
4132	ZS6541	Gasket oven 60 H=8.9 mat HT	1
4521	ZS7088	Turnspit hole cap	1
6128	ZC0296	Side muffle oven 30/60/90 enamelled 04 grey	2
6270	GP0195	Assembly rear muffle oven 60/100 TC enamelled grey	1
1401	ZS2585	Tapping screw M5 aluminium	4
6272	ZA0488	Circular tangential oven 90 fan without fan and nut	1
6273	ZA0489	Nut for circular tangential oven	1
6274	ZA0490	Fan for circular tangential oven	1
6278	ZC0349	Enamelled muffle ceiling oven 60 grey	1
6283	ZC0356	Enamelled drip tray for oven 60 grey	1
6300	ZC0360	Enamelled muffle bottom for oven 60 grey	1
6328	ZC0350	Fan cover for oven 60 with turnspit hole grey	1

3025






N° Object	Code	Description	Qty
3025	GR5115	Assembly glued oven door 60 G/100 triple oven Ascot	1
2941	GR4317	Assembly door 60 right bar profile 07	1
2942	GR4318	Assembly door 60 left bar profile 07	1
1222	ZS2309	Inner glass oven door 60 G	1
1257	ZS2391	In-between glass oven door 60 G 04	1
1339	ZS2416	Door hinge for multifunction oven 60	2
1280	ZS2419	Spring for door glass assembling 04	4
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
3051	ZS5115	Glued external oven door 60 G/100 triple oven	1
5193	ZS8177	Handle for oven door 60 Ascot 70/100 chromed terminal nickel	1




N° Object	Code	Description	Qty
82	481403	Thermoswitch 16 Ampere	1
103	482072	Upper heating element cooker	1
123	541011	Spacer washer for built-in oven	2
128	601152	Spring fixing feeler for built-in oven	2
188	ZS7653	Lower heating element for oven 30	1
1209	414559	Lateral frame support for built-in oven	6
1217	ZS2283	Oven lateral frame 30/60/90	2
1220	ZS2287	Chromed wire grid for oven 30	1
1260	ZS2395	Hinge support 06	2
1303	ZS2454	Lower heating elem.support oven 30 04	1
1304	ZS2455	Lower heating element tray oven 30 04	1
1319	ZS2488	Trivet for oven 30 04	1
1413	ZS2599	Gasket oven 30 04	1
1422	ZS2627	White glass wool for rear side 30 oven 04	1
1423	ZS2628	White glass wool for 30 oven 04	1
1467	ZS2604	Support for safety thermostat 04	1
1760	ZS3078	Telescopic liner left	1
1761	ZS3079	Telescopic liner right	1
4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	1
5932	ZP0119	Turnspit hole cap	1
6128	ZC0296	Side muffle oven 30/60/90 enamelled 04 grey	2
6277	ZC0348	Enamelled muffle ceiling oven 30 grey	1
6282	ZC0355	Enamelled drip tray for oven 30 grey	1
6286	ZC0361	Muffle rear side oven 30 enamelled grey	1
6298	ZC0351	Enamelled muffle front side oven 30 grey	1
6299	ZC0359	Enamelled muffle bottom for oven 30 grey	1
6301	ZC0365	Grill heating element support for muffle oven 30 enamelled grey	1

2716



N° Object	Code	Description	Qty
2716	GR4330	Assembly glued oven door 30 s.steel Ascot	1
2937	GR4313	Assembly door 30/60/90 right bar profile 07	1
2938	GR4314	Assembly door 30/60/90 left bar profile 07	1
1224	ZS2311	Inner glass oven door 30	1
1256	ZS2390	In-between glass oven door 30 04	1
1277	ZS2414	Door hinge for oven 60 G	2
1280	ZS2419	Spring for door glass assembling 04	4
1381	ZS2546	Glued external oven door 30 KL	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
5192	ZS8176	Handle for oven door 30 Ascot 100/120 chromed terminal nickel	1



N° Object	Code	Description	Qty
18	400006	Protection door	2
391	ZS0899	Couple legobox rails partial opening	1
817	ZS0458	Drawer right regulation clip	1
818	ZS0459	Drawer left regulation clip	1
3036	ZS4819	Drawer door cooker 100 triple oven 04	1
3484	ZS5647	"Steel - Stile in cucina" plate	1
4164	ZS6681	Drawer lateral side for cooker S.Steel	2
4613	ZS6837	Bottom drawer for cooker 100 triple oven S.Steel	1
4614	ZS6838	Drawer rear side for cooker 100 triple oven S.Steel	1
4845	ZS7531	Counterdoor drawer cooker 100 TC pull	1
5192	ZS8176	Handle for oven door 30 Ascot 100/120 chromed terminal nickel	1

N° Object	Code	Description	Qty
132	ZS5148	Adhesive tape 16,5 m x 19h (3M)	80
725	601108	Anti-overturning device	0,3
1329	ZS5150	Adhesive tape 33 mt x 25h mm x Th 1.55 mm (3M)	18000
2296	ZS2666	Wiring commutators L=20 cm	4
2307	ZS3763	Wiring leds Party	1
2430	ZS2996	Wire protection d.3,5 vetrotex white	0,8
5050	ZS7813	Instruction booklet Top/Cooker Multilanguage	1
6117	ZA0635	Wiring diagram for cooker S10FFF-6I	1