



N° Object	Code	Description	Qty
98	481913	Terminal board for oven 32 PA 233	1
1014	ZS2026	Thermostat TY60 N.O. fixing B	1
1439	ZS2663	Tangential oven fan L=180 Plaset (AU)	1
3640	ZS5704	Left guard for oven 060/090	1
3641	ZS5705	Right guard for oven 060/090	1
3642	ZS5706	Upper guard for oven AGF 060	1
3643	ZS5707	Lower guard for oven AGF 060	1
3644	ZS5708	Rear guard for oven AGF 060	1
3646	ZS5710	Air conveyor for oven 060/060 DC	1
3648	ZS5712	Rear support for muffle left/right side oven	2
3755	ZS6050	Control panel Ascot oven 60 S.STEEL	1
3925	ZS6277	Muffle fan guard oven AGF 060 Ascot	1
3935	ZS6313	Lateral handle	4
4027	ZS6323	Bezel for oven temperature	1
4029	ZS6331	Bezel for function oven	1
4031	ZS6335	Programmer control panel AGF Ascot CHROME with serygr.	1
4107	ZS6596	Thermoswitch 16 Ampere	1
4177	ZS6694	Commutator support 1 control	2
4276	ZS6809	Bracket condensate collection 60 complete	1



N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
455	ZS1075	Thermostat for built-in oven	1
538	ZS1204	Led transparent	2
539	ZS1205	Fluorescent green warning light	1
823	ZS1755	Fluorescent orange warning light	1
2067	ZS3785	Knob for timer black	5
3330	ZS5412	Knob Ascot chromed	2
3867	ZS6012	Electrical display support	1
3922	ZS6184	Timer (white led) LCD-ELA 1000	1
4006	ZS6538	Commutator oven fast heat functions	1



N° Object	Code	Description	Qty
2728	GR4342	Assembly glued oven door 60/100 double oven Ascot	1
2937	GR4313	Assembly door 30/60/90 right bar profile 07	1
2938	GR4314	Assembly door 30/60/90 left bar profile 07	1
1334	ZS2308	Inner glass oven door 60	1
1337	ZS2393	In-between glass oven door 60 04	1
1339	ZS2416	Door hinge for multifunction oven 60	2
1280	ZS2419	Spring for door glass assembling 04	6
1383	ZS2550	Glued external oven door 60/100 double oven	1
1968	ZS3586	Handle for oven door 60 Ascot 70/100 chromed	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1



## Forno Ascot AFE6 SS-C Steel 230/50 EU

001

N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
89	481727	Tangential oven 90 fan (AU) with fan and nut	1	4132	ZS6541	Gasket oven 60 H=8.9 mat HT	1
128	601152	Spring fixing feeler for built-in oven	2	4296	ZS9953	Lower heating elem.support oven 60	2
714	401764	Handle M55/60 PH/WH U.K. for oven grill pan	1	4574	ZS6005	Fixing support for turnspit motor oven 60/90	1
1209	414559	Lateral frame support for built-in oven	6	4821	ZS9948	Grill heating element for oven 60 (1900+850W)	1
1217	ZS2283	Oven lateral frame 30/60/90	2				
1219	ZS2286	Chromed wire grid for oven 60	1				
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2				
1230	ZS2322	Enamelled muffle ceiling oven 60	1				
1231	ZS2324	Enamelled muffle bottom for oven 60	1				
1232	GR2326	Assembly rear muffle oven 60/100 enamelled 04	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
1248	ZS2364	Enamelled drip tray for oven 60	1				
1260	ZS2395	Hinge support 06	2				
1320	ZS2489	Trivet for oven 60 04	1				
1325	ZS2496	Grill heating element support for muffle oven 60 enamelled 04	1				
1333	ZS2289	Support for grillrod 60/90	1				
1346	ZS2484	Fan cover for oven 60 with turnspit hole BLACK	1				
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1424	ZS2629	White glass wool for rear side 60 oven 04	1				
1425	ZS2632	White glass wool for 60 oven 04	1				
1832	482094	Grill heating element for oven 60 (1900+850W)	1				
2891	482589	Circular heating element 230V-2100W	1				
3259	ZS5174	Turnspit for oven 60 (4 forks + handle) - 04	1				
3261	ZS5236	Turnspit motor reducer 50/60 Hz	1				
3919	ZS6002	Reinforce for fixing support for turnspit motor oven 60/90	1				
3923	ZS6193	Lower heating element tray oven 60 04	1				
4016	ZS6193	Lower heating element tray oven 60 04	1				
4115	ZS6631	Compete Lamp-holder for oven (max 25 W)	1				



N° Object	Code	Description	Qty
2225	ZS3976	Gasket aerostop	2
3718	ZS6027	Wiring diagram for oven 60 ascot	1
3924	ZS6201	Instruction booklet Ovens IT	1
4082	ZS6505	Aluminium badge "Steel - Stile in cucina"	1
4141	ZS6666	Instruction booklet Ovens DE	1
4142	ZS6667	Instruction booklet Ovens GB	1
4236	ZS6670	Instruction booklet Ovens FR	1
4238	ZS6712	Instruction booklet Ovens NL	1