



N° Object	Code	Description	Qty
129	601154	Timer	1
1014	ZS2026	Thermostat TY60 N.O. fixing B	1
1957	ZS3495	Washer 4.3 x 10 x 3	4
1996	ZS3171	Blocking plate hob-side Party	2
3717	ZS6026	Switch for induction encoder	5
4210	ZS5377	Energy regulator for induction 230 V EGO EU	5
4211	ZS5378	Induction 5 element EGO	1
4266	ZS6787	Encoders control board	1
4522	ZS7089	Knob gas burners ATG	6
4668	GR7269	Assembly cooktop cooker 90 induction Prt/Drb	1
4320	ZS6725	Glass for 90 induction hob or cooker	1
4714	ZS6821	Support for electronic control induction element	1
4731	ZS7270	Rear support for induction 5 elements 90 cm	1
4751	ZS7386	Front support for induction 5 elements 90 cm	1
5009	GR8841	Assembly control panel front 6 zone electric oven ENF 90 S.Steel serygr.	1
5801	ZS8317	Display support	1
5753	ZP0068	Thickness for profile	2
5765	ZP0085	Commutator support 3 positions	2
5783	ZS6817	Feet for electronic components EGO	3
5784	ZS6904	Cover for induction terminal board	1
5785	ZS6905	Bridge for induction terminal board	1
5849	ZS8914	Frontal bar profile cooker 90	1



N° Object	Code	Description	Qty
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
455	ZS1075	Oven thermostat	1
538	ZS1204	Led transparent	2
539	ZS1205	Fluorescent green warning light	1
823	ZS1755	Fluorescent orange warning light	1
1588	ZS2889	Commutator oven functions 90 EGO	1
3649	ZS5713	Electrical display support	1
3921	ZS6051	Glass lcd 3 button no holes	1
3936	ZS6334	Timer (blue led) 3 TT SIEBE Touch meat probe	1
4522	ZS7089	Knob gas burners ATG	2
5766	ZP0086	Commutator support 2 positions	1



N° Object	Code	Description	Qty
98	481913	Terminal board for oven 32 PA 233	1
1439	ZS2663	Cooling fan L=180 Plaset (AU)	1
1913	ZS2718	Muffle fan guard cooker 90 cm Prt / Drb	1
1944	ZS2719	Air conveyor for cooktop 090/100 Prb/Drb	1
3054	ZS5128	Ramp hole closing plate	1
3484	ZS5647	"Steel - Stile in cucina" plate	1
5033	ZS7657	Door hinge for drawer door	2
5266	ZS8337	Side external right/left higher ADG S.STEEL	2
5267	ZS8339	Upper guard for drawer 90	1
5268	ZS8340	Front support for muffle left side cooker 90	1
5269	ZS8341	Front support for muffle right side cooker 90	1
5270	ZS8342	Rear support for muffle left/right side cooker 90	2
5271	ZS8343	Rear guard for cooker 90 ADG	1
5309	ZS8457	Drawer door cooker 90 ADG s.steel	1
5310	ZS8458	Counterdoor drawer cooker 90	1
5559	ZA0059	Adjustable feet H100/145 inox ADG	4
5873	GR2717	Assembly complete lower reinforcement 90	1
130	601156	Tapping screw M10 galvanized	4
1912	ZS2717	Lower guard for cooker 090 Party	1

N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
21	401638	Gasket oven 90	1	3261	ZS5236	Turnspit motor reducer 50/60 Hz	1
82	481403	Thermoswitch 16 Ampere	1	4115	ZS6631	Compete Lamp-holder for oven (max 25 W)	2
84	481589	Grill heating element for oven 90	1	4574	ZS6005	Fixing support for turnspit motor oven 60/90	1
89	481727	Circular tangential oven 90 fan (AU) with fan and nut	1				
128	601152	Spring fixing feeler for built-in oven	2				
720	451200	Chromed wire grid for oven 90 AU	1				
1209	414559	Lateral frame support for built-in oven	6				
1217	ZS2283	Oven lateral frame 30/60/90	2				
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2				
1234	ZS2330	Enamelled muffle ceiling oven 90	1				
1235	ZS2332	Enamelled muffle bottom for oven 90	1				
1236	GR2334	Assembly rear muffle oven 90 enamelled 04	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
1237	ZS2336	Enamelled muffle front side oven 90	1				
1249	ZS2366	Enamelled drip tray for oven 90	1				
1260	ZS2395	Hinge support 06	2				
1313	ZS2467	Grill heating element support for muffle oven 90 enamelled 04	1				
1314	ZS2468	Lower heating elem.support oven 90 04	1				
1315	ZS2469	Lower heating element tray oven 90 04	1				
1328	482325	Circular heating element 230V-2500W	1				
1333	ZS2289	Support for grillrod 60/90	1				
1347	ZS2486	Fan cover for oven 90 with turnspit hole 04 BLACK	1				
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1420	ZS2625	White glass wool for rear side 90 oven	1				
1421	ZS2626	White glass wool for 90 oven 04	1				
1467	ZS2604	Support for safety thermostat 04	1				
1839	ZS3082	Lower heating element for oven 90 (1400 W)	1				
3260	ZS5175	Turnspit for oven 90 (4 forks + handle) - 04	1				

4389

1221

4903

1384

5358


2943

4474

5358

4930

2944



N° Object	Code	Description	Qty
4389	GR7026	Assembly glued oven door 90	1
4903	GR7666	Assembly door 30/60/90 right bar profile 15	1
4930	GR8097	Assembly door 30/60/90 left bar profile 15	1
1221	ZS2307	Inner glass oven door 90	1
1384	ZS2552	Glued external oven door 90	1
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1
4474	ZS6996	Door oven handle for oven 90 PLG	1
5358	ZS8596	Door hinge for oven 90	2

N° Object	Code	Description	Qty
131	BS0296	Adhesive tape 4959	600
132	ZS5148	Adhesive tape 16,5 m x 19h (3M)	40
725	601108	Anti-overturning device	0,3
1210	ZS5149	Adhesive tape 33 mt x 17h mm x th 0,6 mm (3M 4930)	200
1329	ZS5150	Adhesive tape 33 mt x 25h mm x Th 1.55 mm (3M)	10000
1586	ZS2770	Additional wiring generic L=60 cm Fem Fem	2
4760	ZS7453	Wiring diagram for cooker P9F-6I	1
5793	ZS7811	Instruction booklet cooker Party MULTILANGUAGE	1