



Rif. Esploso	Codice	Descrizione	Q.ta
98	481913	Terminal board for oven 32 PA 233	1
1014	ZS2026	Thermostat TY60 N.O. fixing B	1
1439	ZS2663	Tangential oven fan L=180 Plaset (AU)	1
3640	ZS5704	Left guard for oven 060/090	1
3641	ZS5705	Right guard for oven 060/090	1
3659	ZS5723	Lower guard for oven AGF 090	1
3660	ZS5724	Rear guard for oven AGF 090	1
3661	ZS5725	Muffle fan guard oven AGF 090 Genesi	1
3663	ZS5770	Upper guard for oven AGF 090	1
3665	ZS5772	Front support for muffle left/right side oven 90	2
3666	ZS5773	Rear support for muffle left/right side oven 90	2
3935	ZS6313	Lateral handle	4
3986	ZS6485	Reinforcement for lower guard oven 90	1
4003	ZS6533	Control panel Genesi oven 90 S.STEEL	1
4070	ZS6481	Air conveyor for oven 090	1
4107	ZS6596	Thermoswitch 16 Ampere	1
4177	ZS6694	Commutator support 1 control	3
4277	ZS6810	Bracket condensate collection 90 complete	1




Rif. Esploso	Codice	Descrizione	Q.ta
94	481814	Commutator multif. for 90 built-in oven(no pizza)	1
455	ZS1075	Thermostat for built-in oven	1
538	ZS1204	Led transparent	2
539	ZS1205	Fluorescent green warning light	1
823	ZS1755	Fluorescent orange warning light	1
2133	ZS3047	Knob for cooker Sintesi SLT	2
3649	ZS5713	Electrical display support	1
3921	ZS6051	Glass lcd 3 holes	1
3936	ZS6334	Timer (blue led) 3 TT SIEBE Touch meat probe	1
4006	ZS6538	Commutator oven fast heat functions	1

2602



Rif. Esploso	Codice	Descrizione	Q.ta
2602	GR2552	Assembly glued oven door 90	1
2937	GR4313	Assembly door 30/60/90 right bar profile 07	1
2938	GR4314	Assembly door 30/60/90 left bar profile 07	1
1049	ZS2131	Door oven handle for oven 90 chromed SLT cooker 90/120	1
1221	ZS2307	Inner glass oven door 90	1
1259	ZS2394	In-between glass oven door 90 04	1
1279	ZS2417	Door hinge for oven 90	2
1280	ZS2419	Spring for door glass assembling 04	4
1384	ZS2552	Glued external oven door 90	1
1575	ZS2931	Spacer between glasses	4
2943	ZS4746	Right support for inner glass	1
2944	ZS4747	Left support for inner glass	1



Rif. Esploso	Codice	Descrizione	Q.ta	Rif. Esploso	Codice	Descrizione	Q.ta
84	481589	Grill heating element for oven 90	1	4115	ZS6631	Complete Lamp-holder for oven (max 25 W)	2
89	481727	Tangential oven 90 fan (AU) with fan and nut	1	4148	ZS6380	Lower heating elem.support oven 90	1
128	601152	Spring fixing feeler for built-in oven	2	4574	ZS6005	Fixing support for turnspit motor oven 60/90	1
714	401764	Handle M55/60 PH/WH U.K. for oven grill pan	2	4651	ZS6536	Lower heating element for oven 90 (1150 W)	1
720	451200	Chromed wire grid for oven 90 AU	1				
1209	414559	Lateral frame support for built-in oven	6				
1217	ZS2283	Oven lateral frame 30/60/90	2				
1225	ZS2312	Side muffle oven 30/60/90 enamelled 04	2				
1234	ZS2330	Enamelled muffle ceiling oven 90	1				
1235	ZS2332	Enamelled muffle bottom for oven 90	1				
1236	GR2334	Assembly rear muffle oven 90 enamelled 04	1				
1401	ZS2585	Tapping screw M5 aluminium	4				
1237	ZS2336	Enamelled muffle front side oven 90	1				
1249	ZS2366	Enamelled drip tray for oven 90	1				
1260	ZS2395	Hinge support 06	2				
1313	ZS2467	Grill heating element support for muffle oven 90 enamelled 04	1				
1321	ZS2490	Trivet for oven 90 04	1				
1328	482325	Circular heating element 230V-2500W	1				
1333	ZS2289	Support for grillrod 60/90	1				
1347	ZS2486	Fan cover for oven 90 with turnspit hole 04 BLACK	1				
1349	ZS2499	Fixing support for turnspit motor oven 60/90	1				
1420	ZS2625	White glass wool for rear side 90 oven	1				
1421	ZS2626	White glass wool for 90 oven 04	1				
3260	ZS5175	Turnspit for oven 90 (4 forks + handle) - 04	1				
3261	ZS5236	Turnspit motor reducer 50/60 Hz	1				
3919	ZS6002	Reinforce for fixing support for turnspit motor oven 60/90	1				
3948	ZS6379	Lower heating element tray oven 90	1				
4053	ZS3394	Gasket oven 90 H=8.9 mat HT	1				

Rif. Esploso	Codice	Descrizione	Q.ta
2428	ZS4303	Hole cap black plastic	4
3257	ZS5157	Gasket aerostop	0,5
3924	ZS6201	Instruction booklet Ovens IT	1
3987	ZS6501	Wiring diagram for oven 90 Genesi	1
4082	ZS6505	Aluminium badge "Steel - Stile in cucina"	1
4141	ZS6666	Instruction booklet Ovens DE	1
4142	ZS6667	Instruction booklet Ovens GB	1
4236	ZS6670	Instruction booklet Ovens FR	1
4238	ZS6712	Instruction booklet Ovens NL	1