


N° Object	Code	Description	Qty
1356	ZS2507	Door oven handle for oven 30 chromed SLT	1
2352	ZS4211	Protection covering BBQ 70	1



N° Object	Code	Description	Qty	N° Object	Code	Description	Qty
19	400689	Gasket gas inlet	1	4711	ZS6772	Clamp support for main ramp	1
392	ZS0903	Sintesi black foot H.15	4	4901	GR4780	Assembly complete control panel BBQ 70	1
797	410645	Pipe holder (G30)	1	2414	ZS4148	Right cap for control panel BBQ	1
997	ZS1645	Bezel for central vitroceramic /grill knob 58, bright chromed	3	2415	ZS4149	Left cap for control panel BBQ	1
1093	410828	Pipe support	1				
1766	ZS3155	Knob 58 for gas burners SLT	3				
2139	ZS3390	Two-sided cast-iron griddle for BBQ	1				
2140	ZS3391	Cast-iron open grid for BBQ	2				
2164	ZS3447	Right side combustion area BBQ	1				
2165	ZS3448	Left side combustion area BBQ	1				
2166	ZS3449	Supports for side top BBQ	4				
2168	ZS3451	Side panel top 90 BBQ	2				
2171	ZS3454	Ramp support for top BBQ	1				
2172	ZS3455	Burners deflector top BBQ	2				
2174	ZS3457	Burners cooktop BBQ	3				
2178	ZS3467	Burners heat spreader top BBQ	2				
2215	ZS3920	Tool for griddle cleaning BBQ	1				
2345	ZS4201	Drip tray top BBQ 70	1				
2346	ZS4202	Support for taps cooking top BBQ 70	1				
2347	ZS4203	Rear cooktop BBQ 70	1				
2348	ZS4204	Ramp 3 burners cooktop BBQ 70	1				
2351	ZS4208	Protection taps cooktop 70 BBQ	1				
3220	ZS4752	Guide for drip tray top BBQ	2				
3484	ZS5647	"Steel - Stile in cucina" plate	1				
3866	ZS4754	Front side combustion area BBQ 70	1				
3914	ZS4753	Rear side combustion area BBQ 70	1				
4417	ZS6807	Tap BBQ burner	3				
4418	ZS6808	Thermocouple BBQ L=300 with 2 nuts included	3				

N° Object	Code	Description	Qty
130	601156	Tapping screw M10 galvanized	4
2205	ZS3753	Tapping screw M5 s.steel	8
2218	ZS3928	Cotter pin "R-shaped" white wire	3
2927	ZS4298	Washer 5.3 x 15 x 1.2 s.steel	2
4805	ZS7550	Fixing spring for front profile	3
5088	ZS7974	Instruction booklet BBQ Caddie Swing Green - Steel Multilanguage	1